
Box Contents

NOTE: Revolabs Wireless Microphones Ship in Separate Box(es)



HD Single Charger Base

OR



HD Dual Charger Base



HD Single/Dual Base Station



3.5mm to 3.5mm cable
HD Single: Quantity 1
HD Dual: Quantity 2



3.5mm to RCA adapter
HD Single: Quantity 1
HD Dual: Quantity 2



Universal power supply
plus plug
Quantity 2

How to Assemble

1. Plug a power clip into each power supply.
2. Plug a power supply into Charger Base and another into Base Station.
3. Plug all power cords into electrical outlets.
4. Plug the 3.5 mm end of the cable(s) into Base Station. If needed, plug 3.5 mm to RCA adapter into one end of the cable.
5. Plug cable(s) into AV equipment.
6. Pair Revolabs Wireless Microphone(s) to Base Station using the pairing instructions.
7. Place microphone(s) into Charger Base.

<https://uc.yamaha.com/resources/support/>

How to Configure Basic Settings

Refer to HD Single/Dual Channel User Guide



Mini-USB Serial Interface
for Firmware Updates Only

Configuration DIP 5 switches

3.5mm Output Connectors

3.5mm Input Connectors

Power

DIP Switch	Feature	Off (Default)		On	
1	Output Mixing	Individual Outputs		Mixed Output	
2	Low Pass Filter	No LPF		LPF	
3	Audio Output Level	Line Level		Mic Level	
4	Mute	Local Mute		No Local Mute	
		Flat	High Boost	Bass Boost	Dynamic
5	Microphone EQ	Off	On	Off	On
6	Microphone EQ	Off	Off	On	On
		150'	100'	50'	15'
7	Transmit Power	Off	On	Off	On
8	Transmit Power	Off	Off	On	On

Regulatory Information (full information in User Guide)

<https://uc.yamaha.com/resources/support/>



Yamaha Unified Communications, Inc.
144 North Road #3250
Sudbury, MA 01776 USA
+1 800-326-1088
uc-sales@music.yamaha.com

Yamaha UC EMEA
190 High Street Tonbridge, Kent
TN9 1BE, UK
+44 (0)1732 366535
uc-salesemea@music.yamaha.com

Yamaha UC APAC
+852.8108.8820
uc-salesapac@music.yamaha.com